

MODEL TO-336

Motorized Flow Table



Applicable standards

- AASHTO T-126

ORDERING INFORMATION

- **TO-336-01** Motorized Flow Table, 110V, 60Hz
- **TO-336-02** Motorized Flow Table, 220V, 60Hz
- **TO-336-03** Motorized Flow Table, 220V, 50Hz

The Flow Table is designed for determining the workability of Portland cement concrete.

The 76.2cm diameter table top is finely machined from a solid brass casting; the stand is made from cast iron. Operation is simple, whereby the ground and hardened steel cam is designed to drop the table by 12.5mm.

PACKAGING INFORMATION

- **Net weight:** 135kg; **gross weight:** 175kg
- **Packaging dimensions:** 102 x 83 x 89cm